


## Bofors Lader Hülsenzahn


Bofors Loader Tooth



Ersatzteil-Nr. Part-no.	L (mm)	A (mm)	B (mm)	H (mm)	K (mm)	Gewicht (kg) Weight	Bolzen Pin	Ring Retainer	Größe Size
30 101 404 7166	258	62	32	36	25	2,5	31 006 404 6816	30 201 625 4673	B0
31 102 404 7167	308	70	37	44	30	4,5	31 004 404 6797	31 201 625 4675	B1
32 101 303 1537	375	85	48	54	35	8,4	32 004 404 6819	32 201 6254677	B2
33 102 303 1539	415	110	52	59	40	11,9	33 004 4046862	33 201 6254682	B3
34 102 303 1542	420	125	47	70	60	22,0	34 004 4044339	33 201 6254682	B4
35 102 303 1386	660	150	54	80	82	38,0	35 003 3031387	35 201 6254679	B5

## Bofors Bagger Hülsenzahn


Bofors Excavator Tooth



Ersatzteil-Nr. Part-no.	A (mm)	B (mm)	C (mm)	D (mm)	Gewicht (kg) Weight	Anschweißhülse Adapter	Sicherung Fastener	Größe Size
30 104 404 6818	36	36	232	62	2,2	31 006 404 6816	30 201 625 4673	B0
31 104 404 6799	42	44	280	65	3,7	31 004 404 6797	31 201 625 4675	B1
32 105 303 2682	54	54	345	80	7,1	32 004 404 6819	32 201 625 4677	B2
33 104 303 1354	59	59	397	100	11,2	33 004 4046862	33 201 625 4682	B3

## Bofors Greifer Hülsenzahn


Bofors Clamshell Tooth



Ersatzteil-Nr. Part-no.	A (mm)	B (mm)	C (mm)	D (mm)	Gewicht (kg) Weight	Anschweißhülse Adapter	Sicherung Fastener	Größe Size
30 103 404 4291	36	36	238	62	2,1	31 006 404 6816	30 201 625 4673	B0
31 103 404 4388	42	44	284	70	3,3	31 004 404 6797	31 201 625 4675	B1
32 106 303 1362	54	54	400	85	6,0	32 004 404 6819	32 201 625 4677	B2

## Bofors Baggerzahn Flach


Bofors Excavator Tooth



Ersatzteil-Nr. Part-no.	A (mm)	B (mm)	C (mm)	D (mm)	Gewicht (kg) Weight	Anschweißhülsen Adapter	Sicherung Fastener	Größe Size
31 101 404 4336	44	44	340	80	6,0	31 003 303 1434	31 201 625 4675	B 1
32 102 404 4428	52	52	408	90	9,7	32 003 303 1394	32 201 625 4677	B 2
33 101 303 1334	58	58	485	100	14,0	33 003 303 1395	33 201 625 4682	B 3
34 101 303 1335	64	64	546	108	20,0	34 003 303 1396	33 201 625 4682	B 4
35 101 303 1336	72	75	595	125	25,5	35 004 303 1397	35 201 625 4679	B 5

## Bofors Baggerzahn Spitz


Bofors Excavator Tooth pointed



Ersatzteil-Nr. Part-no.	A (mm)	B (mm)	C (mm)	D (mm)	Gewicht (kg) Weight	Anschweißhülsen Adapter	Sicherung Fastener	Größe Size
31 107 404 4336 S	41	44	365	-	5,0	31 003 303 1434	31 201 625 4675	B 1
32 103 404 4428	52	52	424	-	7,8	32 003 303 1394	32 201 625 4677	B 2
33 103 303 1364	58	58	502	-	11,6	33 003 303 1395	33 201 625 4682	B 3
34 107 303 1365	62	64	558	-	19,0	34 003 303 1396	33 201 625 4682	B 4
35 107 303 1366	72	75	633	-	25,0	35 004 303 1397	35 201 625 4679	B 5

## Bofors Baggerzahn (Torpedo) Flach


Bofors Torpedo Tooth




Ersatzteil-Nr. Part-no.	Ersatzteil	L (mm)	A (mm)	B (mm)	H (mm)	H (mm)	I (mm)	Gewicht (kg) Weight	Sicherung Fastener
38 107 403 8246	5.000 T	340	75	45	45	115	14	4,8	100 TS 14x80-1481
404 6729	7.500 T	360	80	50	50	114	14	6,7	100 TS 14x80-1481
38 111 403 8257	10.000 T	10	90	57	58	132	20	10,0	240 TS 20x100-1481
38 104 302 7689	15.500 T	510	95	64	64	172	20	15,1	240 TS 20x100-1481
38 101 302 7512	24.000 T	580	110	75	75	211	20	22,0	240 TS 20x100-1481

## Bofors Baggerzahn (Torpedo) Flach

Bofors Torpedo Tooth




Ersatzteil-Nr. Part-no.	Ersatzteil	L (mm)	A (mm)	B (mm)	H (mm)	H (mm)	I (mm)	Gewicht (kg) Weight	Sicherung Fastener
	7.500 TS	405	-	50	50	115	14	6,7	100 TS 14x80-1481
404 6746	10.000 TS	460	-	57	58	132	20	9,5	240 TS 20x100-1481
	15.500 TS	560	-	64	64	172	20	15,1	240 TS 20x100-1481
	24.000 TS	630	-	75	75	211	20	23,0	240 TS 20x100-1481



## Bofors Anschweißhülse

Bofors B-Lock Adapter

Ersatzteil-Nr. Part-no.	L (mm)	A (mm)	H (mm)	Gewicht (kg) Weight	Hülsenzahn Teeth	Sicherung Fastener
31 006 404 6816	121	64	50	0,9	30 101 30 104 30 103	30 201 625 4673
31 004 404 6797	160	77	61	2,0	31 102 31 104 31 103	31 201 625 4675
32 004 404 6819	209	94	74	3,8	32 101 32 105 32 106	32 201 625 4677
33 004 404 6862	216	105	83	5,1	33 102 33 104	33 201 625 4682
34 004 404 4339	238	134	106	8,2	34 102	33 201 625 4682
35 003 303 1387	300	167	123	18,5	35 102	35 201 625 4679



## Bofors B-Lock Sicherung

Bofors B-Lock Fastener

Ersatzteil-Nr. Part-no.	L (mm)	B (mm)	H (mm)	Gewicht (kg) Weight	Größe Size
30 201 625 4673	59	27	8	0,1	B0
31 201 625 4675	73	32	10	0,1	B1
32 201 625 4677	87	35	10	0,2	B2
33 201 625 4682	96	40	11	0,2	B3/B4
35 201 625 4679	120	50	13	0,3	B5